



# Spring Cleaning: Keep your harp in tip-top shape!



## Dust and Grime Removal

Dry cloth  
New Paintbrush  
Damp Cloth  
\*Dish soap

## Check the Strings

Hairy Strings  
Fraying around the tuning pin  
Different texture  
Changing Color

## Replaceable Parts

Strings  
Levers/lever caps  
Tuning Pins  
Pedal Caps  
Pedal Felts  
Shoes and bumpers

## Minor scrape Touch Up

Finish pens  
Almond pens  
light layers

## Check the regulation

Tune open string  
Check engagement  
Adjusting Levers  
Adjusting disks

## Protecting Your Harp

Padded Case  
Transport Cover  
Levers/Pedals not engaged  
\*Use Dust Cover  
Use dolly when moving  
NO WEIGHT on levers or action

## Helpful Resources!

[String Changing Workshop Video with Virginia Harp Center's Amy Roberts](#)

[Lever Harp String Charts](#)

[Regulating Levers](#)

[Replacing Camac Levers](#)

[Tuning a Lever Harp](#)

[Tuning a Pedal Harp](#)

[Changing Pedal Felts with Josh Layne](#)